Game Select Switch Chart

How to use this chart

Up = On or 1
Down = Off or 0

Example:Future Spa 00010010
⇓⇓⇓⇑⇓⇓⇑⇓

Bally Machines

Freedom	00000000
Night Rider	00000001
Evel Knievel	00000010
Eight Ball	00000011
Power Play	00000100
Mata Hari	00000101
Blackjack	00000110
Strikes & Spares	00000111
Lost World	00001000
6 Million $ Man	00001001
Playboy	00001010
Sexy Girl	00001010
Voltan	00001011
Supersonic	00001100
Star Trek	00001101
Kiss	00001110
Paragon	00001111
Harlem Globe	00010000
Dolly Parton	00010001
Future Spa	00010010
Nitro Ground	00010011
Silver Ball Mania	00010100
Rolling Stones	00010101
Mystic	00010110
Hot Doggin	00010111
Viking	00011000
Space Invaders	00011001
SkateBall	00011010
Frontier	00011011
Xenon	00011100
Flash Gordon	00011101
Eight Ball Deluxe	00011110
FireBall II	00011111
Embryon	00100000
Fathom	00100001
Medusa	00100010
Centaur	00100011
Elektra	00100100
BMX	00100101
Mr. & Mrs. Pacman	00100110
Speakeasy 2 player	00100111
Spectrum	00101000
Vector	00101001
Granny & Gators [2]	00101010
Cybernaut	00101011
GoldBall	00101100
FireBall Classic	00101101
Spy Hunter	00101110
X & O's	00101111
Black Pyramid	00110000
Kings of Steel	00110001
Grand Slam	00110010
Rapid Fire	00110011
Baby Pacman [2]	00110100
Speakeasy 4 Player	00110101
Big Bat Baseball [2]	00110110
New Vector [2]	00110111
New Fathom [2]	00111000

Stern Machines

Pinball	01000000
Sting Ray	01000001
Dracula	01000010
Wild Fyre	01000011
Lectronamo	01000100
Nugent	01000101
Magic	01000110
HotHand	01000111
Memory Lane	01001000
Stars	01001001
Trident	01001010
Ali [1]	01001011
Big Game [1]	01001100
Catacomb [1]	01001101
Cheetah [1]	01001110
Dragonfist [1]	01001111
Flight 2000 [1]	01010000
Galaxy [1]	01010001
Iron Maiden [1]	01010010
Lazer Lord [1]	01010011
Lightning [1]	01010100
Meteor [1]	01010101
NineBall [1]	01010110
Orbitor1 [1]	01010111
Quick Silver [1]	01011000
Seawitch [1]	01011001
Split Second [1]	01011010
Star Gazer [1]	01011011
Viper [1]	01011100
FreeFall [1]	01011101
Cosmic Princess	01011110

Note 1: CLK Jumpers need to be on the left side.
Note 2: No freeplay for these games.

Free Play Settings

(Bally Only)

To place any of the Bally games in free play mode, just place the left most switch in the on position. For example lets use Future Spa again.

Example:Future Spa 10010010
⇑⇓⇓⇑⇓⇓⇑⇓

Then turn off your credit display feature which is either switch 20 or 27 of the game feature dipswitches.

Consult our manual or the settings cards located in the game for the correct switch to turn off or just try one or the other.

Enhanced Diagnostics Test

Place the two left most switches in the on position. You can keep the other switches as they are.

Example: 11000000
⇑⇑⇓⇓⇓⇓⇓⇓

Memory Clear Function

Place all the switches in the up position except switch one. See Example.

Example: 01111111
⇓⇑⇑⇑⇑⇑⇑⇑

Other Game Software:

Sexygirl	00001010
Big Ball Bowling [2]	01011111
Blk Sheep Squadron [2]	01100000
Genisis Puck Bowler [2]	01100001
Blk Beauty Shuffle [2]	01100010
Big Bat Baseball [2]	01100011

Table 1

Ver 8